

# **G310GS Tractive Shock (Level 1 & Low)**

## **RRP 838 & 837**

**NOTE : BEFORE COMMENCING WORK ON THE CONVERSION, TAKE TIME TO READ THE INSTRUCTIONS CAREFULLY. ALL WORK CAN BE CARRIED OUT BY A COMPETENT MECHANIC, BUT IF YOU ARE UNSURE PLEASE CONTACT US OR A MECHANICAL PROFESSIONAL.**

**KEEP ALL PARTS THAT ARE REMOVED, AS IT IS POSSIBLE TO REMOVE OUR KITS AND RETURN THE BIKE TO STANDARD, IF REQUIRED**

<b>Level 1 Tractive shock fitting</b>	
Tools needed: <ul style="list-style-type: none"><li>• 5mm Allen key</li><li>• 8mm Allen key</li><li>• Grease</li></ul>	
1. Support bike with stand under engine so that rear wheel is suspended off the floor.	
2. Remove right side plastic panel.	
3. Remove plastic shock shroud.	
4. Undo and remove lower M10 shock bolt, then remove upper M10 bolt, whilst supporting shock.	
5. Remove OEM shock.	
6. Insert new Tractive shock into top mount, make sure the orange adjuster at the bottom is facing to the right, apply grease to M10 bolt and gently insert and tighten gently, do not fully tighten.	
7. Insert lower M10 bolt and fully tighten, then fully tighten upper bolt.	
8. Replace right plastic cover.	
9. Replace plastic shock shroud.	